





> SIP User Agent IETF RFC3261 compliant</li> <li style="border-image: initial; padding: 0px; margin: 0px; border: 0px initial initial;">> SIP over UDP/TCP with optional TLS support (SIP signalling only)</li> <li style="border-image: initial; padding: 0px; margin: 0px; border: 0px initial initial;">> TDM bridging over 2 berofix devices through PCM bus interconnection, 8.192 kB/s</li>

> PCI 2.2 compliant 3.3V (chipset Realtek 8139CL), also fits to 5V slot but 3.3V needed</li> <li style="border-image: initial; padding: 0px; margin: 0px; border: 0px initial initial;">> PCI express 1.1 compliant (chipset Realtek 8111C)</li> <li style="border-image: initial; padding: 0px; margin: 0px; border: 0px initial initial;">> ??????????: 167 x 9,85 x 15mm</li> <li style="border-image: initial; padding: 0px; margin: 0px; border: 0px initial initial;">> ??????: 110g</li> <li style="border-image: initial; padding: 0px; margin: 0px; border: 0px initial initial;">> Operating temperature: 0-70°C</li> <li style="border-image: initial; padding: 0px; margin: 0px; border: 0px initial initial;">> Compliance: CE (EN55022, EN55024, EN60950)</li>

</ul><span style="font-family: Arial, Verdana, 'Helvetica san-serif'; color: #777777;"><span style="font-size: 12px; line-height: 21px;"><a href="images/stories/PDFs/Datasheet\_Box.pdf" target="\_blank"><span style="color: #be4048;"> </span> </a> <ul style="margin-top: 0px; margin-right: 0px; margin-bottom: 20px; margin-left: 0px; border-image: initial; list-style-type: none; list-style-position: inside; padding: 0px;"><span style="text-align: left; color: #bb0000;"><a href="images/stories/PDFs/Datasheet\_Baseboard.pdf" target="\_blank"><span style="color: #be4048;"><span style="color: #be4048;">? Datasheet berofix PCI/PCIe Card</span></span></a> </span> </ul> </span> </td> </tr> </table> <p style="padding-left: 0px; margin-left: 0px; font-family: arial; font-size: 12px;">{tab=Modules & Accessories}</p> <table style="font-family: arial; width: 615px;" border="0" cellspacing="10" cellpadding="0"> <tr> <td style="font-size: 11px; padding-left: 0px; padding-right: 5px; padding-bottom: 5px;"> <p style="padding-left: 0px; margin-left: 0px; font-family: arial; font-size: 12px;"><strong>Modules</strong> </p> <ul style="font-family: Arial, Verdana, 'Helvetica san-serif'; font-size: 10pt; line-height: 21px; color: #777777;"> <li style="border-image: initial; padding: 0px; margin: 0px; border: 0px initial initial;">> 1 Port PRI Module (BF1E1)</li> <li style="border-image: initial; padding: 0px; margin: 0px; border: 0px initial initial;">> 2 Port PRI Module (BF2E1)</li> <li style="border-image: initial; padding: 0px; margin: 0px; border: 0px initial initial;">> 4 Port BRI Module (BF4S0)</li> <li style="border-image: initial; padding: 0px; margin: 0px; border: 0px initial initial;">> 2/2 Port BRI/FXS Hybrid Module (BF2S02FXS)</li> <li style="border-image: initial; padding: 0px; margin: 0px; border: 0px initial initial;">> 4 Port FXO Module (BF4FXO)</li> <li style="border-image: initial; padding: 0px; margin: 0px; border: 0px initial initial;">> 4 Port FXS Module (BF4FXS)</li> <li style="border-image: initial; padding: 0px; margin: 0px; border: 0px initial initial;">> 2 Port GSM Module (BF2GSM)</li> </ul><strong>Accessories</strong> <ul style="font-family: Arial, Verdana, 'Helvetica san-serif'; font-size: 10pt; line-height: 21px; color: #777777;"> <li style="border-image: initial; padding: 0px; margin: 0px; border: 0px initial initial;">> BFBridge (to use all 4 RJ45 slots on a Baseboard with one bf4S0,bf4FXS,bf4FXO,bf2S02FXS)</li> <li style="border-image: initial; padding: 0px; margin: 0px; border: 0px initial initial;">> BFTAdapters (to connect 2 BRI or analog Lines on one RJ45 of the berofix)</li> <li style="border-image: initial; padding: 0px; margin: 0px; border: 0px initial initial;">> BFPCM (PCM Cable to interconnect berofix Baseboards)</li> <li style="border-image: initial; padding: 0px; margin: 0px; border: 0px initial initial;">> BFE1Cross,

(1.8m E1/T1 "cross-over" cable)</li> <li style="border-image: initial; padding: 0px; margin: 0px; border: 0px initial initial;">BF19bracket (19 inch rack mount bracket for berofix Boxes)</li> <li style="border-image: initial; padding: 0px; margin: 0px; border: 0px initial initial;">BFANTS (small 7 cm stock antenna for BF2GSM modules)</li> <li style="border-image: initial; padding: 0px; margin: 0px; border: 0px initial initial;">BFANTL (2m cable antenna with magnetic foot for BF2GSM modules)</li> <li style="border-image: initial; padding: 0px; margin: 0px; border: 0px initial initial;">BFFXXCable (RJ45 to RJ11 cable to use with berofix analog modules)</li> </ul> </td> </tr> </table> <p style="padding-left: 0px; margin-left: 0px; font-family: arial; font-size: 12px;">{/tabs}</p>